

Default Setting for Web GUI RAID Management Tools

Web GUI RAID Tools Instructions

After you install the Web GUI management tools, you can setup the RAID volume using any Web Browser. The following is the default setting:

Web Address: <https://localhost:7402/>

Username: RAID

Password: hpt

For further instruction to setup the RAID, please visit the detailed manual.

www.sansdigital.com | info@sansdigital.com | phone 800 980 1988 | fax 626 322 3878

